


## BOP Cage

**BOP Cage** is used for installing and fixing the BOP during transport the Transport Frame, supporting the BOP on the ground, protect the hydraulic quick joint of the BOP from damaged in lifting process. And it can provide a safe and reliable operation platforms for the operators after connected to the wellhead together with the BOP.

Normally, BOP Cage only provide together with Wireline BOP which fixed on the Transport Frame, not sold separately. Because we must ensure that the BOP Cage fit with Wireline BOP properly. And if you only purchase the Wireline BOP, the BOP Cage will not be included.



### Feature

- 1) Compact size which fit with Wireline BOP fully.
- 2) Proper protection on the BOP when transportation or lifting operation.
- 3) Convenient to use.

### Normal Guarantee Period

12 months after the clients received the Equipment or 13 months after the commodity be shipped from Chinese Harbor.

### Information Required When Inquiry

If you will purchase the whole Wireline PCE, please refer to the [Information Required When Inquiry](#) in Chapter 《Wireline PCE》 .



Subject to change without notice